
























toll free: 1-877-706-4480
international/local: 713-706-4480
fax: 713-706-4161
www.MS3C.co

MS3C Stair Chair Replacement Parts List





toll free: 1-877-706-4480
 international/local: 713-706-4480
 fax: 713-706-4161
www.MS3C.co

<p>1. Controller: MS3C-300CNTRL</p> 	<p>12a. Telescoping Handle: MS3C-TSCPHDL</p> 
<p>2. Telescoping Guide Handle: MS3C-TSCPGHDL</p> 	<p>12b. Replacement Rubber Grip: MS3C-RRG</p> 
<p>3. Rear Push Handle Lock Lever: MS3C-300TSRLL</p> 	<p>13. Footrest: MS3C-300FR</p> 
<p>4. Rear Push Handle: MS3C-300RHDL</p> 	<p>14. Battery Slide: MS3C-BATTERYSLIDE</p> 
<p>5. Telescoping Handle Release Bar: MS3C-THRB</p> 	<p>15. Backrest & Seat Cover: MS3C-SEATCVRS</p> 
<p>6a. Top Track Guide Wheel: MS3C-TWGT</p> 	<p>16. Passenger Assist Handle: MS3C-PAH</p> 
<p>6b. Bottom Track Guide Wheel: MS3C-TWGB</p> 	<p>17. Lap Belt: MS3C-LPBLT</p> 
<p>7. Track: MS3C-CHRTRKS</p> 	<p>18. Shoulder Belt: MS3C-SHLDRBELT</p> 
<p>8. Motor Cover: MS3C-MTRC</p> 	<p>19. Headrest: MS3C-HNREST</p> 
<p>9. Caster Replacement Lock: MS3C-RCL</p> 	
<p>10. Rear Wheel: MS3C-300RW</p> 	
<p>11. Front Wheel: MS3C-300FW</p> 	



toll free: 1-877-706-4480
international/local: 713-706-4480
fax: 713-706-4161
www.MS3C.co

MISC PARTS:

Battery Charger: MS3C-CHRGR 	Motor: MS3C-TSBMOTOR 
Replacement Battery: MS3C-300TSB-B 	Leg Restraint Strap: MS3C-LRS 
Lap Belt Extension: MS3C-300EXBLT 	